

OPERATION GUIDELINES

- 1) Place objects inside the unit.
- 2) Choose desired power setting.


NOTE: Do not turn on unit when it is empty. Pour in adequate cleansing liquid (around 1 cm below the rim). Too much liquid may cause it to spill over electronic parts thus damaging the unit.

30W Power Setting

- a. Press **POWER** to put unit in standby mode. With "99" flashing on the display screen.
- b. Then press the **POWER** button again to start the 30W cleaning setting. The "99"seconds cleaning time starts, and will stop automatically at "00".

50W Power Setting

- a. Press **POWER** to put unit in standby mode. With "99" flashing on the display screen.
 - b. Then press the **POWER** button again, when unit starts working under the 30W cleaning setting. Press the **30W/50W** button once to switch it to the 50W setting. Then the "99"seconds cleaning time starts, and will stop automatically at "00".
- 3) To stop the unit (under any setting) immediately, just press the **POWER** button once.
 - 4) After cleansing, pull off plug first before taking out cleansed objects
 - 5) Clean and dry ultrasonic cleaner after every use.

 **NOTE:** A two minute rest is required after 5 minutes of continuous use. A ten minute rest would be needed after operating it 5 times.

MLINK 105D

DOUBLE POWER ULTRASONIC CLEANER

INSTRUCTION MANUAL

Thank you for purchasing 105D Ultrasonic Cleaner.
Please read the manual before using the unit.
Keep manual in accessible place for future reference.

- Clean. removes dirt and greases.
- Sanitize and sterilizes.
- Stops emulsification.
- Innovative lid that is resistant to acid and alkali base.

PURPOSE

- Designed to clean small electronic parts and PCB's.
- Can also be used to clean jewelry, watches, eyeglasses and other accessories.
- Can also be used to clean small spare parts.

SPECIFICATION

Power Input :	240V / 50 Hz
Power Consumption:	30W / 50W
Operation Frequency:	40 k Hz
Tank Capacity:	500 mL
Working Time:	99 seconds
Tank to Ground Resistance:	$\leq 0.1\Omega$
Tank Dimension:	165(w) x 85(h) x 45(d) mm
Exterior Dimensions:	185(w) x 150(h) x 100(d) mm
Weight:	1 Kg

FEATURES

- Microprocessor controlled.
- Uniquely designed with anti-static function.
- Versatile with two interchangeable power settings: 30W and 50W.
- Digital display of power, working time and working state.
- Driven by continuous high frequency ultrasound for highly effective cleaning result.

CARE and SAFETY PRECAUTIONS



CAUTION: Misuse may cause extensive damage to the unit.
For your own safety, be sure to comply with the following precautions.

- Upon using, please make sure that the plug is properly grounded .
- Do not disassemble/modify unit, high voltage pressure inside unit may cause damages.
- Do not turn on when it is empty. Pour in adequate cleansing liquid. (around 10mm below the rim)
- Do not pour flammable / acidic cleansing liquid.
- Handle with Care
 - Never drop or sharply jolt the unit.
 - Do not beat or drum the bottom of the cleaner.
- Disconnect plug when not to be used for a long period of time.
- It Is normal that the bottom part of the unit gets warm while operating.